

How to use the FLIR ONE Edge thermal imaging camera

These instructions are also available online, together with a video to take you through each step.


To access it go to www.n-somerset.gov.uk/thermalcamera or use this QR code:



Turning on the camera

心	Press the Power button on the front of the camera
\$FLIR	The device has 3 bars on the front which will flash sequentially until they turn to a solid light.
	If the display does not turn on, charge battery via the USB port.

The camera will calibrate occasionally to check the device is measuring accurately. You will hear a sound when this happens, and the image will briefly freeze.






Taking a photo

raking a prioto	
51	Download the FLIR ONE app via Google Play or App Store. The correct app has this logo. Connect the devices together using Bluetooth and follow the on-screen instructions. You do not need to register on the app before use unless required, you can skip through the registration instructions.
Series III SOLIE	Connect the device to the camera as shown. Make sure the device is flat against the back of your phone.
anate	Point the device at a location, you will see the image on the phone camera. Take a photo as normal and save the image to your image gallery.

Investigating specific hot and cold points





Looking at your photos and keeping them

_

When you're finished

U	Press and hold power button on top of camera to turn it off.
\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	Put the camera back into the box along with any cables and information sheets.
	Return the box to your local library.

Look at the enclosed Next Steps information sheet to find ways to fix any issues.